

Echo Indigo for Mac OS X - version 1.4

Thank you for purchasing an Echo Indigo product. We're sure you'll enjoy it!

This installer will only run on OS X 10.2 or later. We recommend that you update to the latest version of OS X.

Installation

1) Double-click "Install Echo Indigo". This will install the main CoreAudio driver. Just follow the on-screen directions.

2) There's no install program for the console; just drag the "Echo Indigo Console" icon wherever you want to keep it. To copy it to your "Applications" folder, just drag it to the "Applications" icon in the Finder window.

After this installation completes, your Indigo card may be inserted at any time.

The driver supports the Cardbus eject feature. Please follow this procedure in order to eject your Indigo:

1. Close all audio applications.
2. Select "Power off Card" from the Cardbus menu in the upper right corner of the screen.
3. Wait till the blue light on your Indigo turns off.
4. You can now safely remove your Indigo.

For more information about the Indigo line of products or Echo's other products please visit us on the web at www.echoaudio.com.

The console

This is the virtual control surface for your Echo hardware. The console is documented in the Indigo Macintosh manual; it can be found either on the CD-ROM that came with your hardware or online at www.echoaudio.com.

Version history

1.4

Corrects a problem where the inputs on Indigo io would not appear on the list of audio devices.

Fixes an issue with Apple DVD Player

1.3

Added support for Indigo io and Indigo dj

Added the console application

1.2

Indigo can now be ejected after selecting Power off Card from the Cardbus menu

Sample rate offset has been decreased for improved latency

Timestamping has been made more accurate

1.01

Sample rate now restored properly on resume from standby

Performance has been improved

New firmware that resolves a rare audio breakup issue

1.00

Initial release