

# Echo Digital Audio Corporation

Indigo IOx

Indigo DJx

Release 1.1 beta for Mac OS X

<b>DISCLAIMER.....</b>	<b>2</b>
<b>RELEASE INFORMATION.....</b>	<b>2</b>
<b>SUPPORTED OPERATING SYSTEMS.....</b>	<b>2</b>
<b>CHANGES .....</b>	<b>3</b>
<b>KNOWN ISSUES .....</b>	<b>3</b>
<b>INSTALLATION .....</b>	<b>4</b>
<b>VERSION HISTORY .....</b>	<b>5</b>

## **Disclaimer**

Please be aware that these drivers are used at your own risk; Echo Digital Audio Corporation is not responsible for any damage or loss incurred by the use of these drivers.

## **Release Information**

This is the second beta release of the Mac OS X drivers for the Indigo ExpressCard products.

## **Supported Operating Systems**

This software is for Intel MacBook computers running Mac OS X 10.4 and later. PowerPC Macs are not supported, as Apple has not manufactured a Macintosh with a PowerPC processor and an ExpressCard slot.

## Changes

- Fixed hardware interrupt sharing
- Changed physical memory handling to support Macs with more than 2.5 GB of RAM
- Adjusted the headphone output level to prevent distortion

## Known issues

- While this software should work with Mac OS X 10.4, it has only been tested with Mac OS X 10.5. If you are using Mac OS X 10.4, please let us know your results.
- Sample rates above 48 kHz are currently not supported.
- The driver does not automatically save and restore mixer settings.
- The sample rate cannot be set from the Indigo ExpressCard console. It can be set from your audio software or from Audio MIDI Setup.

## Installation

1. Drag and drop the Indigo ExpressCard Console to the Applications folder.
2. Open the Indigo ExpressCard driver installer and follow the on-screen directions.
3. Restart your MacBook
4. Insert your Indigo IOx or DJx into your MacBook.

## Version history

### 1.1

- Fixed hardware interrupt sharing
- Changed physical memory handling to support Macs with more than 2.5 GB of RAM
- Adjusted the headphone output level to prevent distortion

### 1.0

- Initial release